



This product must be installed by a qualified electrician in accordance with all national and local electrical and construction codes.
Failure to comply with the installation instructions can result in serious injury or death.



1 MaxiLED Festoon - Cutting the End of Line terminator



(a). Cut off end of line terminator leaving enough cable to allow re termination.

2 Cut desired length



(a). Cut off required amount of extra globes to give the desired length, leaving enough cable to re-terminate the End of Line. (EOL)

3 Prepare cable ends



(a). Prepare both cut ends of the festoon to be re-connected.

4 Fitting IP68 Gel joint



(a). Fit IP68 Gel joint as per manufactures instructions, Ray Tech Fred-N.

(b). Fixture must be installed by a qualified electrician in accordance with all national and local electrical and construction codes.
Failure to comply with the installation instructions can result in Serious injury or death.

5 Re-balance the EOL if required, see link below

[EndofLine_Resistor.pdf \(maxiledlighting.com\)](#)